

## **Easy Pole Swag 9230**

### **What is the difference in pattern 9230 and 9231?**

Pattern 9230 has a swag depth of 15". Each pocket area takes up 8" of rod space. Pattern 9231 has a swag depth of 18". Each pocket area takes up 11" of rod space.

### **Can I alter the swag?**

No. The shape and angles of the pattern would have to change. We cannot help you with that.

### **Can I alter the jabot?**

Yes. Alterations instructions are given.

### **Can I use this swag for an arched window?**

No. The pattern is not shaped for arched windows.

### **Can I use these swags for a bay window?**

Yes, except you cannot overlap them at the corners. Swags cannot turn a corner. They would need to butt. A tail or jabot is then used to fill the gap.