

## **Arched Window Swag II 9233**

**These swags will fit windows 42” to 54” wide only (measuring straight across half circle at the widest place). We cannot give you alteration instructions. Angles and shape of the pattern would have to change. We can’t help you with that.**

**Chapter 6B in our “Manual Collection” will teach you how to create gathered swag patterns, any size, any shape.**

**I need at least a 5” projection for these swags to clear some vertical blinds. Is this possible?**

No. These swags are installed directly to the window frame. There is no board, no rod, no projection. Hook and loop tape is used. Additional stapling can be added under the pleats, if more support is needed.

**Can I adapt the swags to only three instead of four?**

No, 9233 nor 9232 can be altered in any way.

**Can I use a holdback to install the side swags?**

Only three holdbacks can be used. The bottom of the swags finish too wide, and must be installed with hook and loop tape to the window facing.