



## Flat Back Hobble Shades

9219 D

Instructions are for a “flat back” hobble shade. This shade holds fullness in every fold, even when shade is all the way down. An additional lining will place behind the hobble folds. The lift bands, rings, and ribs will attach to that lining (the flat back).

**Fabric Suggestions:** While deciding on your fabric, keep in mind weight and window width. If your fabric and lining are heavy and your window is over 100” wide, you may need a motorized lift system. Blackout lining is recommended for the flat back but not for the shade itself. Unlined sheer fabrics are not recommended.

### YARDAGE

The pattern and instructions offer double fullness in the shade.

**Shade fabric**.....Finished length x 2”. Plus 8” for hems.  
The cut width should be 8” wider than finished width.

**Shade lining** (regular).....Cut length of shade, less 6”.

**Shade interlining** .....Cut length of shade, less 6”.

**Flat back** (blackout lining).....Finished width x finished length plus 2”.

**Facing** (shade fabric) .....2 strips 6” wide x same cut length as flat back.

**Trim** (optional).....Finished width plus 2”.

### Sure Shade™ Lift System [www.RowleyCompany.com](http://www.RowleyCompany.com)

There is a revolution in window treatments involving lift cords as we have known them. Cords at the back of a fabric shade can pull out and form a loop. A young child can become tangled in the cords and be strangled. The Sure-Shade™ System components, upon using the appropriate fabrication techniques, will meet the standards of the American National Standards Institute (ANSI) dated September 3, 2010. Bead chain, or cord loop, complies with the standards if properly installed to the wall and the Universal Drive Tension Device is used.

Instructions in this package include using the Sure Shade™ lift system components involving the roller tube and lift bands. The components needed are listed inside. Simplified instructions to assemble the system is also given. Contact the Rowley Company to order the supplies, or a kit.

This lift system must be installed to a mount board, or to the wall, if a pole is used for the shade.