


## TIP OF THE MONTH MARCH 2006

### REVERSE SHAMS

A reverse sham is an alternative choice to a pillow tuck. 35" of fabric length should be added to the bedspread length. After the bedspread is finished, except for the outside edges, this 35" should be cut off, reversed, and attached back to the bedspread.



Notice that the bedspread drop stays neat and in place all the way to the head of the bed. Only the side drop on the sham takes up the bulk of the pillow.

Taken (in part) from  
M'Fay Workroom Manual.